


Installation Operation Manual Training Kit Variable Frequency Drive VFD




Industrial IoT EduTic.id

1. Bagian Kit Trainer

✓ Bagian Depan




✓ Bagian Belakang





2. Unit Inverter/VFD Bagian Depan



3. Unit Inverter/VFD Bagian Belakang



4. Diagram Port Kontroler



5. Indikator pada Layar VFD

- L1 (LOCK)** : Indikator bahwa tombol terkunci
- L2 (FWD)** : Indikator motor dalam putaran Forward
- L3 (REV)** : Indikator motor dalam putaran Reverse
- L4 (POWER)** : Indikator Power
- L5 (RS-485)** : Indikator Komunikasi data RS-485

6. Fungsi tombol pada VFD

1. Tombol **K1 (view/shift)** untuk merubah nilai tampilan pada layar, nilai yang ditampilkan sebagai berikut :
 - (1) Fxx.x: Menampilkan nilai frekuensi driver.
 - (2) t-xx: Menampilkan nilai Suhu driver VFD.
 - (3) Cx.xx: Menampilkan nilai Arus listrik.
 - (4) xxx.x: Menampilkan nilai Tegangan DC internal.
 - (5) xxxx: menampilkan nilai RPM motor.
2. Tombol **K2 (menu/exit)** untuk masuk ke menu setting, ataupun keluar dari menu setting.
3. Tombol **K3 (Save/Lock)** untuk menyimpan setting atau mengunci semua tombol. Jika tidak ada interaksi pada tombol selama lebih dari 3 menit, maka tombol akan terkunci secara otomatis. Untuk membukanya tekan tombol **K3 (Save/Lock)** selama 5 detik.
4. Tombol **K4 (FWD/REV)** untuk merubah arah putaran motor.
5. Tombol **K5 (arah atas)** untuk navigasi menu setting/ menambah nilai control.
6. Tombol **K6 (On/Off)** untuk menyalakan/mematikan motor dan select pada menu setting.
7. Tombol **K7 (arah bawah)** untuk navigasi menu setting/ mengurangi nilai control.
8. Tombol **VR (potensio knob)** untuk mengatur nilai frekuensi VFD.

7. Cara Merubah Setting VFD


1. Tekan Tombol **K2 (menu/exit)**.
2. Akan tertampil angka, angka tersebut merupakan nomor **parent code** setiap parameter setting
3. Tekan tombol **K5 (arah atas)** atau **K7 (arah bawah)** untuk menggeser nomor
4. Jika sudah tertuju pada nomor parent code yang diinginkan , tekan tombol **K6 (On/Off)**
5. Akan muncul angka yang berisi nilai dari parent code (subitem code), silakan rubah sesuai tujuan Menggunakan tombol **K5** atau **K7 (lihat tabel reverensi)**.
6. Jika sudah, tekan Tombol **K6 (On/Off)** untuk memilih dan kembali ke menu **parent code**.
7. Untuk menyimpan setting, silahkan tekan tombol **K3 (Save/Lock)**, pada layar akan muncul tulisan **SAVE**, silahkan tekan kembali tombol **K3 (Save/Lock)** untuk menyimpan setting.

8. Tabel Code Parameter Setting VFD

No.	Parent code	Content	Subitem code	Factory value
1	-0.1-	Set start time	Setting range: 1-15 (corresponding time 5s-0.1s)	7
2	-0.2-	Set stop time	Setting range: 1-15 (corresponding time 5s-0.1s)	7
3	-0.3-	Minimum frequency compensation	Setting range: 5-15	8
4	-0.4-	Set compensation maximum frequency	Setting range: 5.0-30.0Hz	20
5	-0.5-	Set the highest frequency voltage ratio of compensation	Setting range: 25-85	55
6	-0.6-	Maximum frequency limiting voltage ratio	Setting range: 80-128	128
7	-0.7-	Rs485 baud rate	0:48(4800) 2:192(19200) 1:96(9600) 3:384(38400)	96
8	-0.8-	Rs485 format, ASCII	1:8N1 3:8E1 2:8N2 4:801	8N1
9	-0.9-	Machine number	1~255	1
10	-1.0-	Source of working frequency	0: Panel keyboard control	1
			1: Panel potentiometer control	
			2: External analog signal input (output voltage is 0-5V) or external potentiometer	
			3: RS485 (RS485)	
11	-1.1-	Start/stop source of control	0: Panel keyboard control	0
			1: RS485 (RS485)	
			2: Turn forward when power on	
			3: Turn reverse when power on	
12	-1.2-	Parking method	0: Inertia stop	1
			1: Deceleration stop	
			2: Brake stop	
			3: Undefined (customizable)	
13	-1.3-	M * function selection	0: M1 forward rotation / stop, M2 reverse rotation / stop	0
			1: M1 operation / stop, M2 reverse rotation / forward rotation	
			2: M1 operation / stop, M2 section speed	
14	-1.4-	M0 function selection	0: Indication in operation	0
			1: Set arrival indication	
			2: Fault indication	
15	-1.5-	Overload protection selection	Undefined	
16	-1.6-	Over temperature protection selection	40°C~100°C	90°C
17	-1.7-	Maximum frequency setting	1.0~99.0Hz	50
18	-1.8-	Minimum operating frequency	1.0~30.0Hz	1
19	-1.9-	Working frequency	1.0~99.0Hz	50
20	-2.0-	Corresponding frequency of the highest output voltage	35.0~99.0Hz	50
21	-2.1-	Segment speed 1 setting	1.0~99.0Hz	5
22	-2.2-	Segment speed 2 setting	1.0~99.0Hz	10
23	-2.3-	Segment speed 3 setting	1.0~99.0Hz	20
24	-2.4-	Segment speed 4 setting	1.0~99.0Hz	25
25	-2.5-	Segment speed 5 setting	1.0~99.0Hz	35
26	-2.6-	Segment speed 6 setting	1.0~99.0Hz	40


27	-2.7-	Segment speed 7 setting	1.0~99.0Hz	45
28	-2.8-	Operating arrival frequency	1.0~99.0Hz	45
29	-2.9-	Undefined (customizable)
30	-3.0-	Current display selection	1: percentage	1
31	-3.1-	Undefined (customizable)
32	-3.2-	Braking frequency at stop	0.0-50.0Hz	0
33	-3.3-	Braking time	0.0-5.0S	0
34	-3.4-	Braking coefficient	0-30%	0
35	-3.5-	Polar logarithm	1~6	2
36	-3.6-	Motor slip	0.01~1.00	1
37	-3.7-	Rated speed of motor	1~9999	1500
38	-3.8-	Segment speed 0 setting	1.0~99.0Hz	1
39	-9.1-	Restore default value	Display flashing CLE, press start / stop key to restore	
40	-9.5-	Reset MCU	Display flashing - 8.88, press start / stop key to restore	-8.88

8. Koneksi Terminal Power



Simbol	Keterangan
U	Motor Terminal U
V	Motor Terminal V
W	Motor Terminal W
	Grounding
F	Fasa - Input Power 220VAC
N	Netral - Input Power Netral

9. Koneksi Port RS-485



9. Alamat Modbus Inverter/VFD

MODBUS-RTU Protocol Specification V1.3						
The data in the protocol include: hexadecimal number, integer, BCD code, floating point number						
Register address the attributes in the following table refer to the read-write attributes of data:						
		R-read	W-write	R / W-read and write		
attribute	address(hex/w ord)	Register length(word)	data type	describe	explain	Remarks (for example)
Collect data information						
R	0	2	UINT	--	Display panel firmware version number	--
R	1	2	UINT	--	Power driver board firmware version number	--
R/W	2	2	UINT	Hz	Inverter speed setting and speed feedback	500/10=50.0Hz
R/W	3	2	UINT	--	Inverter start stop and running state feedback	1: forward 2: stop 5: reverse
R	4	2	--	--	--	spare
R	5	2	--	--	--	spare
R	6	2	--	--	--	spare
R	7	2	--	--	--	--
R	8	2	UINT	V	Bus voltage value	3100/10=310.0 V
R	9	2	UINT	A	Bus current value	132/100=1.32A
R	10	2	UINT	°C	Radiator temperature	43=43°C

10. Detail Dimensi Kit Trainer

